

(DEMO)

ORDER NO.
RRV1271

Service Manual

STEREO CD CASSETTE DECK RECEIVER

XR-P150

THIS MANUAL IS APPLICABLE TO THE FOLLOWING MODEL(S) AND TYPE(S).

Type	Model	Power Requirement	The voltage can be converted by the following method.
	XR-P150		
NB XK	○	AC230V	_____
MEX K/EA	○	AC220V-230V	_____
MEX K/EB	○	AC220V-230V	_____
SD	○	AC110-115V/120-127V/220-230V/240V	With the voltage selector

● For the circuit and mechanism descriptions, refer to the service guide RRV1301 for XR-P150.

CONTENTS

1. SAFETY INFORMATION	2	6. IC INFORMATION	56
2. EXPLODED VIEWS, PACKING AND PARTS LIST	4	7. FL INFORMATION	59
3. SCHEMATIC AND PCB CONNECTION DIAGRAMS	16	8. FOR MEX K/EA, MEX K/EB AND SD TYPES	61
4. PCB PARTS LIST	37	9. PANEL FACILITIES	64
5. ADJUSTMENTS	41	10. SPECIFICATIONS	66

1. SAFETY INFORMATION

This service manual is intended for qualified service technicians; it is not meant for the casual do-it-yourselfer. Qualified technicians have the necessary test equipment and tools, and have been trained to properly and safely repair complex products such as those covered by this manual. Improperly performed repairs can adversely affect the safety and reliability of the product and may void the warranty. If you are not qualified to perform the repair of this product properly and safely, you should not risk trying to do so and refer the repair to a qualified service technician.

WARNING

Lead in solder used in this product is listed by the California Health and Welfare agency as a known reproductive toxicant which may cause birth defects or other reproductive harm (California Health & Safety Code, Section 25249.5).

When servicing or handling circuit boards and other components which contain lead in solder, avoid unprotected skin contact with the solder. Also, when soldering do not inhale any smoke or fumes produced.

NOTICE

(FOR CANADIAN MODEL ONLY)

Fuse symbols  (fast operating fuse) and/or  (slow operating fuse) on PCB indicate that replacement parts must be of identical designation.

REMARQUE

(POUR MODÈLE CANADIEN SEULEMENT)

Les symboles de fusible  (fusible de type rapide) et/ou  (fusible de type lent) sur CCI indiquent que les pièces de remplacement doivent avoir la même désignation.


(FOR USA MODEL ONLY)

1. SAFETY PRECAUTIONS

The following check should be performed for the continued protection of the customer and service technician.

LEAKAGE CURRENT CHECK

Measure leakage current to a known earth ground (water pipe, conduit, etc.) by connecting a leakage current tester such as Simpson Model 229-2 or equivalent between the earth ground and all exposed metal parts of the appliance (input/output terminals, screwheads, metal overlays, control shaft, etc.). Plug the AC line cord of the appliance directly into a 120V AC 60 Hz outlet and turn the AC power switch on. Any current measured must not exceed 0.5 mA.



AC Leakage Test

ANY MEASUREMENTS NOT WITHIN THE LIMITS OUTLINED ABOVE ARE INDICATIVE OF A POTENTIAL SHOCK HAZARD AND MUST BE CORRECTED BEFORE RETURNING THE APPLIANCE TO THE CUSTOMER.

2. PRODUCT SAFETY NOTICE

Many electrical and mechanical parts in the appliance have special safety related characteristics. These are often not evident from visual inspection nor the protection afforded by them necessarily can be obtained by using replacement components rated for voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this Service Manual.

Electrical components having such features are identified by marking with a  on the schematics and on the parts list in this Service Manual.

The use of a substitute replacement component which does not have the same safety characteristics as the PIONEER recommended replacement one, shown in the parts list in this Service Manual, may create shock, fire, or other hazards.

Product Safety is continuously under review and new instructions are issued from time to time. For the latest information, always consult the current PIONEER Service Manual. A subscription to, or additional copies of, PIONEER Service Manual may be obtained at a nominal charge from PIONEER.

(FOR EUROPEAN MODEL ONLY)

VARO !

AVATTAESSA JA SUOJALUKITUS
OHITETTAESSA OLET ALTTIINA
NÄKYMÄTTÖMÄLLE LASERSÄTEILYLLE.
ÄLÄ KATSO SÄTEESEEN.

ADVERSEL:

USYNLIG LASERSTRÅLING VED ÅBNING
NÅR SIKKERHEDSAFBRYDERE ER UDE AF
FUNKTION UDGÅ UDSÆTTELSE FOR
STRÅLING.

VARNING !

OSYNLIG LASERSTRÅLNING NÅR DENNA
DEL ÄR ÖPPNAD OCH SPÄRREN
ÄR URKOPPLAD. BETRÄKTA EJ STRÅLEN.



LASER
Kuva 1
Lasersäteilyn
varoituserkki

WARNING !

DEVICE INCLUDES LASER DIODE WHICH
EMITS INVISIBLE INFRARED RADIATION
WHICH IS DANGEROUS TO EYES. THERE IS
A WARNING SIGN ACCORDING TO PICTURE
1 INSIDE THE DEVICE CLOSE TO THE LASER
DIODE.



LASER
Picture 1
Warning sign for
laser radiation

IMPORTANT

THIS PIONEER APPARATUS CONTAINS
LASER OF CLASS 1.
SERVICING OPERATION OF THE APPARATUS
SHOULD BE DONE BY A SPECIALLY
INSTRUCTED PERSON.

LASER DIODE CHARACTERISTICS

MAXIMUM OUTPUT POWER: 5 mw
WAVELENGTH: 780 - 785 nm

LABEL CHECK

MEXK/EA, MEXK/EB and
NBXK types

**CLASS 1
LASER PRODUCT**
ARW1046

NBXK type

**CAUTION
INVISIBLE LASER RADIATION
WHEN OPEN, AVOID
EXPOSURE TO BEAM**
ARW1050

NBXK type

ADVARSEL USYNLIG LASERSTRÅLING VED ÅBNING NÅR SIKKERHED SAF- BRYDERE ER UDE AF FUNKTION. UDGÅ UDSÆTTELSE FOR STRÅLING. VARO ! Avattaessa ja suojalukitus ohitetta- essa olet alttiina näkymättömälle lasersäteilylle. Älä katso säteeseen.	VORSICHT ! UNSICHTBARE LASER-STRÄHLUNG TRITTT AUS, WENN DECKEL/ODER KLAPPEINGEÖFFNET IST! NICHT DEM STRAHL AUSSETZEN! VARNING ! Osynlig laserstrålning när denna del är öppnad och spärren är urkopplad. Betrakta ej strålen.
--	---

MEXK/EA and MEXK/EB types

**CLASS 1
LASER PRODUCT**
ARW1046

MEXK/EA and MEXK/EB types

Additional Laser Caution

1. Laser Interlock Mechanism

The position of the switch (S601) for detecting loading
state is detected by the system microprocessor, and the
design prevents laser diode oscillation when the switch
(S601) is not on CLMP terminal side (CLMP signal is OFF
or high level.) Thus, the interlock will no longer function if
the switch (S601) is deliberately set to CLMP terminal
side. (low level)

The interlock also does not function in the test mode*.
Laser diode oscillation will continue, if pin 1 of M51593FP
(IC101) on the PRE-AMP BOARD ASSY mounted on the
pickup assembly is connected to GND, or pin 19 is
connected to low level (ON), or else the terminals of Q101
are shorted to each other (fault condition).

2. When the cover is opened, close viewing of the objective
lens with the naked eye will cause exposure to a Class 1
laser beam.

*92S1B

* Refer to page 48.


2. EXPLODED VIEWS, PACKING AND PARTS LIST

NOTES :

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The $\triangle$ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.

2.1 PACKING


Mark	No.	Description	Parts No.
	1	FRONT PAD	AHA7054
	2	REAR PAD	AHA7055
	3	PACKING CASE	AHD7135
	4	PACKING SHEET	AHG7001
	5	FM ANTENNA ASSY	ADH1019
	6	LOOP ANTENNA ASSY	ATB1012
	7	REMOTE CONTROL UNIT (CU-XR015)	AXD7030
NSP	8	BATTERY COVER	AZA7050
	9	BATTERY (R03, AAA)	PEM1004
	10	OPERATING INSTRUCTIONS (English)	ARB7033
	11	QUICK SET UP GUIDE (English)	ARB7039
	12	SPACER	AHB7006



2.2 EXTERIOR (1/3)

Mark No.	Description	Part No.
NSP 1	CD SINGLE MECHA ASSY	RXA1672
2	CD HOLDER L	ANG7023
3	CD HOLDER R	ANG7024
4		
5		
A 6	VOL. KNOB	AAB7051
7		AAK7136
8	DECK WINDOW L	AAK7137
9	DECK WINDOW R	AAK7139
10	TRAY CAP	AAK7142
11	MOLD	AZN7210
12	BONNET	BBZ30P080FZK
13	SCREW	BBZ30P180FMC
14	SCREW	AAK7138
15	FL WINDOW	VRW-329
16	CAUTION LABEL (G)	ARW1046
NSP 17	CAUTION LABEL (F)	ARW1050
NSP 18	CAUTION LABEL	

About flexible JP wire being caught by flame.



NOTE : Screws adjacent to V mark on the product are used for disassembly.

Mark No.	Description
----------	-------------

A
I
B





2.4 EXTERIOR (3/3)

Mark No. Description


1	DISPLAY ASSY
2	EJECT SW ASSY
3	HEADPHONE ASSY
4	FLEXIBLE FLAT CABLE (21P)
5	FLEXIBLE FLAT CABLE (17P)
6	WIRE WITH TERMINAL
7	CONNECTOR ASSY (5P)
8	CONNECTOR ASSY (3P)
9	MECHANISM UNIT
10	DAMPER ASSY
11	EJECT SPRING L
12	EJECT SPRING R
13	EJECT ARM L
14	EJECT ARM R
15	SCREW
16	SPRING
17	COLLAR
18	FUNCTION BUTTON
19	DOLBY BUTTON
20	TIMER BUTTON
21	EJECT BUTTON L
22	EJECT BUTTON R
23	STOP BUTTON
24	STANDBY LENS
25	FRONT PANEL
26	CASSETTE DOOR L
27	CASSETTE DOOR R
28	SCREW
29	SCREW
30	DOOR SPRING L
31	DOOR SPRING R
32	CORD BINDER

Parts No.



AWZ7504	ADXT1802
AWZ7513	ADXT7045
AWZ7514	ADXT7046
ADD1121	RYM1235
ADD7004	VXA1053
	ABHT028
	ABHT029
	AMR7024
	AMR7025
	BSZ20P120FMC
	RBK1004
	RNK2135
	AAD7170
	AAD7172
	AAD7173
	AAD7174
	AAK7177
	AAK7140
	AZN7207
	AZN7208
	AZN7209
	VPZ30P080FZK
	ABA1005
	ABHT060
	ABHT061
	DNF1128



Fit earth lead with screw




Refer to "2.6 MECHANISM UNIT"




2.5 CD SINGLE MECHA ASSY

Mark No.	Description	Parts No.
1	LEVER SWITCH (CLAMP, S601)	DSK1003
2	FLOAT SCREW	PBA1008
3	RUBBER BELT	PEB1193
4	MOTOR PULLEY	PNW1634
5	TRAY	PNW2455
6	PROAT BASE	PNW2032
7	DRIVE GEAR 2	PNW2369
8	GEAR PULLEY	PNW2034
9	CLAMPER BASE	PNW2375
10	CLAMP CAM	PNW2364
11	DC MOTOR0.75W (LOADING)	PXM1010
12	FLOAT RUBBER B (NBXK, MEXK/E, MEXK/EB TYPES)	PEB1287
12	FLOAT RUBBER (SD TYPE)	PEB1014
13	FLOAT RUBBER G (NBXK, MEXK/E, MEXK/EB TYPES)	PEB1288
13	FLOAT RUBBER (SD TYPE)	PEB1132
14	SCREW	BFZ26P080FMC
15	SCREW	Z39-019
16	SCREW	PNM26P040FMC
17	PINION GEAR	PNW2055
18	DC MOTOR (CARRIAGE)	PXM1027
19	DC MOTOR ASSY (SPINDLE)	PEA1235
20	CARRIAGE BASE	PNW2445
21	DISC TABLE	PNW1608
22	SCREW	JFZ20P030FNI
23	SCREW	JFZ17P025FZK
24	GEAR 3	PNW2054
25	GEAR 2	PNW2053
26	WASHER	WT12D032D025
27	PICKUP ASSY	PEA1291
28	GUIDE BAR	PLA1004
29	GEAR 1	PNW2052
30	GEAR STOPPER	PNB1303
31	SCREW	BFZ20P060FMC
32	PWB HOLDER	PNW2057
33	SCREW	BFZ26P100FMC
34	EARTH LEAD UNIT	PDE1104
35	SCREW	BBZ26P060FMC
36	MECHANISM BOARD ASSY	PNWX1192
37	CLAMP MAGNET	PMF1014
38	YOKE	PNB1216
39	H RUBBER	PNB1249
40	CLAMPER S	PNW1609
41	LOADING BASE	PNW2376
42	DC MOTOR ASSY (CARRIAGE)	PEA1246
43	SERVO MECHANISM ASSY	AXA7017
44	CONNECTOR ASSY (4P)	RDE1043
46	CONNECTOR ASSY (5P)	PDE1239



How to install the disc table

- 1 Use nipper or other tool to cut the three sections marked (A) figure 1. Then remove the spacer.
- 2 While supporting the spindle motor shaft with the stopper, put spacer on top of the motor base (angled so it doesn't touch section (B)), and stick the disc table on top (takes about 9kg pressure). Take off the spacer.




2.6 MECHANISM UNIT

- Mechanism unit I and II (1/2)

Mark	No.	Description	Part's No.
	1	ASSY MOTOR	RXM1080
	2	JUMPER WIRE	RDD1012
	3	BRACKET MOTOR	RNE1830
	4	SPACER	RNK1822
	5	SCREW	RBA1100
	6	SCREW	PC220P0013M

● Mechanism unit I and II (2/2)

Mark	No.	Description	Partic No.
1	ASSY HOLDER HEAD (*)	RXA400	45
2	ASSY ARM ASSEMBLY (*)	RXA400	46
3	ASSY ARM ASSEMBLY (*)	RXA400	47
4	ASSY ARM ASSEMBLY (*)	RXA400	48
5	ASSY ARM ASSEMBLY (*)	RXA400	49
6	ASSY ARM ASSEMBLY (*)	RXA400	50
7	ASSY ARM ASSEMBLY (*)	RXA400	51
8	ASSY ARM ASSEMBLY (*)	RXA400	52
9	ASSY ARM ASSEMBLY (*)	RXA400	53
10	ASSY ARM ASSEMBLY (*)	RXA400	54
11	ASSY ARM ASSEMBLY (*)	RXA400	55
12	ASSY ARM ASSEMBLY (*)	RXA400	56
13	ASSY ARM ASSEMBLY (*)	RXA400	57
14	ASSY ARM ASSEMBLY (*)	RXA400	58
15	ASSY ARM ASSEMBLY (*)	RXA400	59
16	ASSY ARM ASSEMBLY (*)	RXA400	60
17	ASSY ARM ASSEMBLY (*)	RXA400	61
18	ASSY ARM ASSEMBLY (*)	RXA400	62
19	ASSY ARM ASSEMBLY (*)	RXA400	63
20	ASSY ARM ASSEMBLY (*)	RXA400	64
21	ASSY ARM ASSEMBLY (*)	RXA400	65
22	ASSY ARM ASSEMBLY (*)	RXA400	66
23	ASSY ARM ASSEMBLY (*)	RXA400	67
24	ASSY ARM ASSEMBLY (*)	RXA400	68
25	ASSY ARM ASSEMBLY (*)	RXA400	69
26	ASSY ARM ASSEMBLY (*)	RXA400	70
27	ASSY ARM ASSEMBLY (*)	RXA400	71
28	ASSY ARM ASSEMBLY (*)	RXA400	72
29	ASSY ARM ASSEMBLY (*)	RXA400	73
30	ASSY ARM ASSEMBLY (*)	RXA400	74
31	ASSY ARM ASSEMBLY (*)	RXA400	75
32	ASSY ARM ASSEMBLY (*)	RXA400	76
33	ASSY ARM ASSEMBLY (*)	RXA400	77
34	ASSY ARM ASSEMBLY (*)	RXA400	78
35	ASSY ARM ASSEMBLY (*)	RXA400	79
36	ASSY ARM ASSEMBLY (*)	RXA400	80
37	ASSY ARM ASSEMBLY (*)	RXA400	81
38	ASSY ARM ASSEMBLY (*)	RXA400	82
39	ASSY ARM ASSEMBLY (*)	RXA400	83
40	ASSY ARM ASSEMBLY (*)	RXA400	84
41	ASSY ARM ASSEMBLY (*)	RXA400	85
42	ASSY ARM ASSEMBLY (*)	RXA400	86
43	ASSY ARM ASSEMBLY (*)	RXA400	87
44	ASSY ARM ASSEMBLY (*)	RXA400	88
45	ASSY ARM ASSEMBLY (*)	RXA400	89
46	ASSY ARM ASSEMBLY (*)	RXA400	90
47	ASSY ARM ASSEMBLY (*)	RXA400	91
48	ASSY ARM ASSEMBLY (*)	RXA400	92
49	ASSY ARM ASSEMBLY (*)	RXA400	93
50	ASSY ARM ASSEMBLY (*)	RXA400	94
51	ASSY ARM ASSEMBLY (*)	RXA400	95
52	ASSY ARM ASSEMBLY (*)	RXA400	96
53	ASSY ARM ASSEMBLY (*)	RXA400	97
54	ASSY ARM ASSEMBLY (*)	RXA400	98
55	ASSY ARM ASSEMBLY (*)	RXA400	99
56	ASSY ARM ASSEMBLY (*)	RXA400	100
57	ASSY ARM ASSEMBLY (*)	RXA400	101
58	ASSY ARM ASSEMBLY (*)	RXA400	102
59	ASSY ARM ASSEMBLY (*)	RXA400	103
60	ASSY ARM ASSEMBLY (*)	RXA400	104
61	ASSY ARM ASSEMBLY (*)	RXA400	105
62	ASSY ARM ASSEMBLY (*)	RXA400	106
63	ASSY ARM ASSEMBLY (*)	RXA400	107
64	ASSY ARM ASSEMBLY (*)	RXA400	108
65	ASSY ARM ASSEMBLY (*)	RXA400	109
66	ASSY ARM ASSEMBLY (*)	RXA400	110
67	ASSY ARM ASSEMBLY (*)	RXA400	111
68	ASSY ARM ASSEMBLY (*)	RXA400	112
69	ASSY ARM ASSEMBLY (*)	RXA400	113
70	ASSY ARM ASSEMBLY (*)	RXA400	114
71	ASSY ARM ASSEMBLY (*)	RXA400	115
72	ASSY ARM ASSEMBLY (*)	RXA400	116
73	ASSY ARM ASSEMBLY (*)	RXA400	117
74	ASSY ARM ASSEMBLY (*)	RXA400	118
75	ASSY ARM ASSEMBLY (*)	RXA400	119
76	ASSY ARM ASSEMBLY (*)	RXA400	120
77	ASSY ARM ASSEMBLY (*)	RXA400	121
78	ASSY ARM ASSEMBLY (*)	RXA400	122
79	ASSY ARM ASSEMBLY (*)	RXA400	123
80	ASSY ARM ASSEMBLY (*)	RXA400	124
81	ASSY ARM ASSEMBLY (*)	RXA400	125
82	ASSY ARM ASSEMBLY (*)	RXA400	126
83	ASSY ARM ASSEMBLY (*)	RXA400	127
84	ASSY ARM ASSEMBLY (*)	RXA400	128
85	ASSY ARM ASSEMBLY (*)	RXA400	129
86	ASSY ARM ASSEMBLY (*)	RXA400	130
87	ASSY ARM ASSEMBLY (*)	RXA400	131
88	ASSY ARM ASSEMBLY (*)	RXA400	132
89	ASSY ARM ASSEMBLY (*)	RXA400	133
90	ASSY ARM ASSEMBLY (*)	RXA400	134
91	ASSY ARM ASSEMBLY (*)	RXA400	135
92	ASSY ARM ASSEMBLY (*)	RXA400	136
93	ASSY ARM ASSEMBLY (*)	RXA400	137
94	ASSY ARM ASSEMBLY (*)	RXA400	138
95	ASSY ARM ASSEMBLY (*)	RXA400	139
96	ASSY ARM ASSEMBLY (*)	RXA400	140
97	ASSY ARM ASSEMBLY (*)	RXA400	141
98	ASSY ARM ASSEMBLY (*)	RXA400	142



FM F.E.

Q801: RF AMP

Q810: MIX AMP

NOTE: VOLTAGE AND CURRENT

①: Signal voltage at FM 1kHz, 100% MOD.

②: DC voltage (V) at no input signal unless otherwise noted.

③: Value in () is DC voltage at rated power.

④: mA: DC current at no input signal unless otherwise noted.

SCH-2

	AXQ3213	AXQ1012
*1	R8288	0
*2	C8230	0.027
*3	C8232	0.027
*4	C8232	0.033
*5	C8232	0.033
*6	C8232	0.033
*7	C8232	0.033
*8	C8232	0.033
*9	C8232	0.033
*10	C8232	0.033
*11	C8232	0.033
*12	C8232	0.033
*13	C8232	0.033
*14	C8232	0.033
*15	C8232	0.033
*16	C8232	0.033
*17	C8232	0.033
*18	C8232	0.033
*19	C8232	0.033
*20	C8232	0.033
*21	C8232	0.033
*22	C8232	0.033
*23	C8232	0.033
*24	C8232	0.033
*25	C8232	0.033
*26	C8232	0.033
*27	C8232	0.033
*28	C8232	0.033
*29	C8232	0.033
*30	C8232	0.033
*31	C8232	0.033
*32	C8232	0.033
*33	C8232	0.033
*34	C8232	0.033
*35	C8232	0.033
*36	C8232	0.033
*37	C8232	0.033
*38	C8232	0.033
*39	C8232	0.033
*40	C8232	0.033
*41	C8232	0.033
*42	C8232	0.033
*43	C8232	0.033
*44	C8232	0.033
*45	C8232	0.033
*46	C8232	0.033
*47	C8232	0.033
*48	C8232	0.033
*49	C8232	0.033
*50	C8232	0.033
*51	C8232	0.033
*52	C8232	0.033
*53	C8232	0.033
*54	C8232	0.033
*55	C8232	0.033
*56	C8232	0.033
*57	C8232	0.033
*58	C8232	0.033
*59	C8232	0.033
*60	C8232	0.033
*61	C8232	0.033
*62	C8232	0.033
*63	C8232	0.033
*64	C8232	0.033
*65	C8232	0.033
*66	C8232	0.033
*67	C8232	0.033
*68	C8232	0.033
*69	C8232	0.033
*70	C8232	0.033
*71	C8232	0.033
*72	C8232	0.033
*73	C8232	0.033
*74	C8232	0.033
*75	C8232	0.033
*76	C8232	0.033
*77	C8232	0.033
*78	C8232	0.033
*79	C8232	0.033
*80	C8232	0.033
*81	C8232	0.033
*82	C8232	0.033
*83	C8232	0.033
*84	C8232	0.033
*85	C8232	0.033
*86	C8232	0.033
*87	C8232	0.033
*88	C8232	0.033
*89	C8232	0.033
*90	C8232	0.033
*91	C8232	0.033
*92	C8232	0.033
*93	C8232	0.033
*94	C8232	0.033
*95	C8232	0.033
*96	C8232	0.033
*97	C8232	0.033
*98	C8232	0.033
*99	C8232	0.033
*100	C8232	0.033

Q801: FM/AM IF DETECTION-PM STEREO DECODER

Q817: FORCED MONO DRIVE

Q803: CONSTANT-VOLTAGE POWER SUPPLY

SIGNAL ROUTE
 (A) : AUDIO SIGNAL ROUTE
 (AM) : AM SIGNAL ROUTE
 (FM) : FM SIGNAL ROUTE

To AF assy (3/3) CN0009 SCH-5

SCH-2


FM/AM TUNER MODULE

FM/AM TUNER MODULE

SCH-2

3.3 AF ASSY, SECONDARY ASSY, PRIMARY ASSY, HEADPHONE ASSY, CD SINGLE MECHA ASSY, MECHANISM UNIT (1/2)

AF ASSY (1/3)
(AWZ7503 : J SD)
(AWZ7501 : NBXK, MEKK/EA, MEKK/EB)



SCH-3

AF ASSY (1/3), MECHANISM UNIT (1/2)


SCH-3


AF ASSY (1/3), MECHANISM UNIT (1/2)

Waveforms

Note: The encircled numbers denote measuring point in the schematic diagram.

*2 FOCUS-IN: Press the key without loading a disc.






IC8151 (CXA1372Q)

Pin No.	Voltage [V]	Pin No.	Voltage [V]	Pin No.	Voltage [V]	Pin No.	Voltage [V]
1	2.5	13	2.5	25	5.0	37	2.0
2	2.5	14	2.5 to 2.6	26	0.1	38	2.7 to 2.8
3	2.5	15	2.5	27	4.9	39	2.5
4	2.5	16	0.8	28	0	40	3.2
5	2.4	17	1.3	29	0	41	0
6	2.5	18	2.5	30	0	42	2.5
7	2.6	19	0	31	0	43	2.5
8	2.5	20	5.0	32	2.7	44	2.5
9	2.5	21	5.0	33	5.0	45	2.5
10	5.0	22	4.9	34	1.3	46	2.5
11	2.5	23	5.0	35	1.0	47	2.5
12	2.5	24	4.9 to 5.0	36	5.0	48	2.4

IC8301 (CXD2508AQ)

Pin No.	Voltage [V]	Pin No.	Voltage [V]	Pin No.	Voltage [V]	Pin No.	Voltage [V]
1	0.1	21	5.0	41	2.4	61	2.0
2	0.1	22	0	42	2.4	62	0
3	5.0	23	5.0	43	2.4	63	0
4	0.1	24	5.0	44	2.4	64	2.5
5	4.9	25	2.6 to 2.7	45	2.4	65	0
6	0	26	0.1	46	1.8	66	0
7	2.2 to 2.5	27	5.0	47	1.8	67	0
8	5.0	28	0	48	0	68	5.0
9	4.9	29	2.7	49	4.9	69	2.5
10	5.0	30	2.6	50	1.2	70	2.5
11	4.9	31	2.6	51	4.9	71	5.0
12	0	32	5.0	52	2.5	72	5.0
13	4.9	33	0	53	0	73	2.4
14	0.1	34	2.7	54	0	74	2.4
15	4.9 to 5.0	35	5.0	55	4.9	75	0
16	5.0	36	2.7	56	4.5	76	0
17	4.9	37	0	57	0	77	2.5
18	0	38	0	58	0 to 0.3	78	2.5
19	0	39	2.5	59	2.8	79	0
20	0	40	0	60	1.4	80	0




SCH-5

AF ASSY (2/3), SECONDARY ASSY
PRIMARY ASSY, HEADPHONE ASSY⁷ TO DISPLAY ASSY CN9102 (SCH-6)

TO DISPLAY ASSY CN9101 (SCH-6)

AF ASSY (3/3), SECONDARY ASSY
PRIMARY ASSY, HEADPHONE ASSY


SCH-5



mounted parts side



DISPLAY ASSY (AWZ7505 : J)
(AWZ7506 : SD)



The parts mounted on this PCB include all necessary parts for several destinations. For further information for respective destinations, be sure to check with the schematic diagram.



4. PCB PARTS LIST

NOTES:

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
 - The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
 - Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
 - When ordering resistors, first convert resistance values into code form as shown in the following examples.
- Ex. 1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5%, and K = 10%).

560 Ω $\rightarrow$ 56 $\times 10^1 \rightarrow$ 561 RD1/8P[5][6][1] J
47k Ω $\rightarrow$ 47 $\times 10^3 \rightarrow$ 473 RD1/4P[5][4][7][3] J
0.5 Ω $\rightarrow$ 0R5 RN2H[0][R][5] K
1 Ω $\rightarrow$ 010 RS1P[0][1][0] K
When there are 3 effective digits (such as in high precision metal film resistors).

Ex. 2 5.62k Ω $\rightarrow$ 562 $\times 10^1 \rightarrow$ 5621 RM1/4P[5][6][2][1] F

Mark No.	Description	Parts No.	Mark No.	Description	Parts No.
----------	-------------	-----------	----------	-------------	-----------

LIST OF ASSEMBLIES

NSP	COMPLEX ASSY	AWK7113	Q4305, Q4357, Q4456	XDA124EK	
NSP	AF ASSY	AWZ7501	Q8302, Q8403, Q8404	XDA143EK	
NSP	DISPLAY ASSY	AWZ7504	Q4455	XDC124EK	
NSP	SECONDARY ASSY	AWZ7508	Q1983	XDC143EK	
NSP	PRIMARY ASSY	AWZ7509	D1007, D1103-D1106, D1981, D1984	ISS254	
NSP	ELECT SW ASSY	AWZ7513		ISS254	
NSP	HEADPHONE ASSY	AWZ7514		ISS254	
	FM/AM TUNER MODULE	AXQ3313		ISS254	

NSP	CD SINGLE MECHA ASSY	RXA1672	D1011	MTZ71, 2B	
NSP	SERVO MECHANISM ASSY SL	AXA7017	D1001, D1005, D1006, D1009	S\$6883	
NSP	MECHANISM BOARD ASSY	PWX1192	D1012-D1015, D1021-D1028, D1983	S\$6883	
			D2201, D2202	S\$6883	

AF ASSY

SEMICONDUCTORS

IC1981, IC1982	BU6094BCF				
IC421	CXA1101P				
IC481	CXA1172Q				
IC8301	CX2308AQ				
IC8201, IC8202	LA6530				
IC1001	NM7906FA				
IC1005	NM7906FA				
IC1002	NM7906FA				
IC201	PNM006A				
IC1201	TDK7265				
IC1501, IC4301, IC4301, IC8401	XR4458F-P				
IC2104, IC1108, Q1261, Q4201, Q4202	XR04053BCF				
Q4204, Q4401, Q4402	2SA1162				
Q1101	2SA1162				
	2SB1340				
	2SB560				
Q1009	2SB2240				
Q4356	2SC2712				
Q1105, Q1107, Q1202, Q1262	2SC2712				
Q4301, Q4302, Q4451-Q4454	2SC2712				
Q8401, Q8402	2SD1781K				
Q4353, Q4354	2SD1889				
Q1102	2SD2144S				
Q4355	2SK346				
Q4307, Q4308	2SK373				

COILS AND FILTERS

L1201, L1202 (5.3 μ H)	LAU1R21				
L8321	LTA4721				
L4301, L4302	LTA4721				
L4303, L4304	LTA4721				
F4401, F4402	RTT1209				

TRANSFORMERS

T4351	ATX-043				
-------	---------	--	--	--	--

CAPACITORS

C4361 (2000P/630V)	ACE1020				
C4319, C4320	CCSC1271K500				
C4323, C4324, C4322	CCSC0CH100D50				
C8407-C8410	CCSC0CH12150				
C1505, C1506, C4323	CCSC0CH20250				
	CCSC0CH21150				
C4353	CCSC0CH21150				
C4403-C4406	CCSC0CH21150				
C4401, C4402	CCSC0CH21150				
C4425, C4436	CCSC0CH21150				
C8155	CCSC0CH21150				
C4151, C4152, C4355	CCSC0CH61150				
C4101, C4102, C4201, C4202	CEAS100M16				
C1009, C1010, C4359, C4360, C4364	CEAS100M30				
C4405, C4407, C4454	CEAS100M30				
C4401, C4408, C4365	CEAS101M10				
C1103, C1104	CEAS101M16				
C1217, C1218	CEAS20M25				
C1002, C4453	CEAS20M30				
C1001	CEAS20M63				
C2213, C2214, C4313	CEAS221M10				

Mark No.	Description	Parts No.
----------	-------------	-----------

C1105, C1106	CEAS221M25	
C1211, C1212	CEAS222M35	
C1005, C1006, C1008, C1501-C1504	CEAS2R2M50	
C4107, C4108	CEAS2R2M50	
C4301-C4304, C4315, C4316	CEAS2R2M50	
C4403, C4404, C4451, C4452	CEAS2R2M50	
C8411, C8412	CEAS2R2M50	
C4309, C4310, C8175, C8176	CEAS331M10	
C8301	CEAS331M10	
C4357	CEAS3R3M50	

C4305, C4306, C4317, C4318	CEAS470M10	
C1261, C4218	CEAS470M16	
C8160, C8162	CEAS4R7M50	
FR300, C1513, C1514	CEAS4R7M50	
C4402, C4406	CEAS4R8M50	
C1220	CKCYB103K50	
C4363	CKCYB222K500	
C4312-C4317	CKCYF473Z50	
C2212	CKCYX104M16	
C2203, C2209, C8171, C8310-C8312	CKSQYB102K50	

C8321	CKSQYB102K50	
C8306	CKSQYB152K50	
C4313, C4314	CKSQYB182K50	
C2152-C2154	CKSQYB221K50	
C4307, C4308	CKSQYB273K50	
	CKSQYB332K50	
C8170	CKSQYB472K50	
C1102, C1107, C8172	CKSQYB473K50	
C1357, C1538	CKSQYB562K50	
C2208	CKSQYB62K50	
C4103, C4104, C4203, C4204	CKSQYB822K50	
C2210, C2211	CKSQYB822K50	
C1981, C4312	CKSQYB823K25	
C4311, C1982, C4352, C4354, C8157	CKSQYF03250	
C8164, C8167, C8169, C8207, C8210	CKSQYF04250	
C8215, C8218-C8220, C8308, C8361	CKSQYF10250	
	CKSQYF15250	

C1003, C1004, C1007, C1551	CKSQYF224Z25	
C2206, C2207, C8158, C8159, C8161	CKSQYF33250	
C8165, C8202, C8303, C8324, C8362	CKSQYF47250	
C4409, C4410	QOMA10350	
C4358	QOMA123K250	
C1203-C1206	CKSQYF724Z25	
C8156, C8168	CKSQYF04250	
C1509, C1510, C8307	CKSQYF47250	
C4362	QOMA562K400	
C2204, C2205	QOMA66350	

RESISTORS

VR4301, VR4302, VR4301 (4.7k)	RCPI1020	
VR8151, VR8152 (22k)	RCPI046	
VR4351, VR4352 (220k)	RCPI049	
VR4101, VR4102, VR4201, VR4202 (470k)	RCPI049	
VR301 (100k-B $\times$ 2)	RCX7010	
R4371	RD12PM470	
R4357	RD12PM6830	
R1201, R1202	RD14PM102J	
	RD14PM133J	
R1221	RD14PM487J	
R1206	RD14PMF77J	
	RD14PMF77J	
R1017	RD16PM110J	
R1213, R1214	RD16PM102J	
R4281	RD16PM103J	
R1993-R1995, R2105, R2106	RD16PM152J	
R1207		
R4363		

Mark No.	Description	Parts No.
----------	-------------	-----------

R1507	RD16PM221J	
R1987, R1988	RD16PM473J	
R1205	RD16PM487J	
R2202	RD16PM513J	
R2201	RD16PM752J	
Other Resistors	RS1/05C[10]	

OTHERS

CN8131	MT CONNECTOR	
CN8202	MT CONNECTOR 4P	
CN8203	MT CONNECTOR 5P	
CN2101	PIN JACK 2P (VIDEO/AUX)	
CN1201	SPEAKER TERMINAL 4-P	
	CABLE HOLDER	
CN4003	2P TOP POST	
CN4002	3P TOP POST	
CN4001	4P TOP POST	
CN9002	FFC CONNECTOR 17P	
CN9001	FFC CONNECTOR 21P	
CN9	14P PLUG	
CN1251	CONNECTOR (5P)	
CN8201	HEAT SINK	
	4P SIDE POST	
X8401 (33.668MHz)		

DISPLAY ASSY SEMICONDUCTORS

IC1901	IC13701-IC13703	
	Q1701-Q1704, Q1706-Q1708	
	Q4505, Q4506	
	Q4501	

Q1705, Q1709, Q1901	2SC7712	
Q4503, Q4504	2SD1781K	
Q4507, Q4508	XDA124EK	
Q1902	XDC143EK	
D1901-D1903, D1905, D3701-D3704	ISS254	
	ISS254	
D4501-D4504, D9001-D9007, D9011	ISS254	
D1705, D1707	DEL1130	
D1701, D1704, D1706, D1708	BR3371X130A	
D4506	MTZ23.0B	
D1904	MTZ26.2B/C	

COILS AND FILTERS

L1901	LAU22020	
-------	----------	--

SWITCHES AND RELAYS

S9001-S9018, S9020, S9021	ASG1051	
---------------------------	---------	--

CAPACITORS

C1901 (4700 μ F)	ACH1246	
C1905	CCSC0H102J50	
C3710, C3711	CCSC0H33J150	
C1908	CEAS100M30	
C1910	CEAS20M10	
C1903	CEAS470M16	
C1907	CEAS4R7M50	
C3701, C3702	CKSQYB12K50	
C3707, C3708	CKSQYB182K50	
C3704, C3705	CKSQYB82K50	

Mark	No.	Description	Parts No.
		C1902, C1904, C1906, C1909, C1911 C3703, C3706, C3709, C3712	CKSQYF473Z50 CKSQYF473Z50

RESISTORS

R1944	RD1/4PM102J
R1712	RD1/6PM101J
R1908-R1910, R1943, R1945-R1948	RD1/6PM102J
R4508	RD1/6PM103J
R1975	RD1/6PM105J
R1708	RD1/6PM121J
R1976-R1978	RD1/6PM222J
R1911, R1914	RD1/6PM332J
R4504	RD1/6PM362J
Other Resistors	RS1/10S□□□J

OTHERS

V1901	FL TUBE CABLE HOLDER REMOTE RECEIVER UNIT	AAV7012 AKT1023 GPIU28X
CN9102	FFC CONNECTOR 17P	HLEM17R-1
CN9101	FFC CONNECTOR 21P	HLEM21R-1
X1902	FL HOLDER (8.00MHZ)	VNF1087 ASS1015

SECONDARY ASSY**SEMICONDUCTORS**

IC1301, IC1302	ICP-N50
D1201-D1204, D1206, D1207	S5688G
D1301-D1304	S5688G

CAPACITORS

C1302	CEAS102M16
C1301	CEAS222M16
C1213	CEAS331M50

OTHERS

CABLE HOLDER	AKT1023
--------------	---------

PRIMARY ASSY**CAPACITORS**

C1101 (0.01μ F/400V)	ACG1002
----------------------	---------

OTHERS

H1101, H1102 FUSE HOLDER	VKR1001
--------------------------	---------

EJECT SW ASSY**SWITCHES AND RELAYS**

S9019	ASG1051
-------	---------

HEADPHONE ASSY**SEMICONDUCTORS**

D2502	MTZJ2.4A/B
-------	------------

COILS AND FILTERS

L2502	LAU100J
-------	---------

RESISTORS

R1251, R1252	RS1LMF331J
Other Resistors	RS1/10S□□□J

OTHERS

CN1252 JACK CABLE HOLDER	AKN1028 AKT1012
-----------------------------	--------------------

Mark	No.	Description	Parts No.
------	-----	-------------	-----------

FM/AM TUNER MODULE**SEMICONDUCTORS**

IC6201	LA1836M
IC6202	LM7001J
Q6102	2SC2223
Q6203	2SC2235
Q6202	2SC2712
Q6103, Q6214	2SC2714
Q6201	2SK208
Q6104	2SK302
Q6101	3SK194
Q6204	XDA124EK
Q6217	XDC124EK
D6101, D6102	1T33

COILS AND FILTERS

L6104	ATC1003
L6101	ATC1020
L6102	ATC1021
L6207 (10.7MHZ)	ATE1013
F6203, F6204	ATF-119
F6101	ATF-155
F6202 (450KHZ)	ATF1155
L6103 (2.2μ H)	ATH1043
L6202, L6203, L6208	LCTA2R2J3225

TRANSFORMERS

T6101	ATE-063
-------	---------

CAPACITORS

C6234, C6236, C6270 (1μ F/16V)	ACG1051
C6107	CCSCH010C50
C6229	CCSCH821J50
C6110	CCSQCH020C50
C6101	CCSQCH050C50
C6108, C6203, C6269	CCSQCH101J50
C6111, C6116, C6208, C6221, C6222	CCSQCH150J50
C6115	CCSQCH330J50
C6114	CCSQRH080D50
C6113	CCSQRH180J50
C6105	CCSQTH150J50
C6261	CEAS010M50
C6224, C6246, C6262	CEAS100M50
C6216, C6217	CEAS330M16
C6231, C6233	CEAS3R3M50

C6219	CEAS470M10
C6243-C6245	CEAS470M16
C6227	CEAS470M25
C6238	CEJA100M16
C6249, C6250	CEJA4R7M35

C6215	CFTXA103J50
C6214	CFTXA224J50
C6103, C6106, C6112, C6204	CKSQYB102K50
C6102, C6109, C6117, C6210, C6264	CKSQYB103K50
C6213	CKSQYB223K50

C6230	CKSQYB273K50
C6228	CKSQYB472K50
C6209, C6237, C6265, C6267	CKSQYB473K50
C6252	CKSQYB822K50
C6212, C6218	CKSQYF103Z50

C6220, C6226, C6239, C6242, C6255	CKSQYF223Z50
C6235	CKSQYF224Z25
C6225, C6241, C6266	CKSQYF473Z50
C6232	CKSYB273K50
C6251	CKSYB822K50

Mark	No.	Description	Parts No.
	C6223		CKSYF103Z50
	C6263		CKSYF473Z50
RESISTORS			
	VR6201	(10k)	ACP1056
	VR6202		VRTB6VS223
	R6299, R6300		RD1/6PM102J
	R6113, R6116, R6118, R6268-R6271		RS1/8S000J
	R6275, R6276, R6278, R6283, R6284		RS1/8S000J
	R6290, R6293, R6294, R6297		RS1/8S000J
	R6243, R6244		RS1/8S101J
	R6211		RS1/8S103J
	R6237		RS1/8S182J
	R6209		RS1/8S221J
	R6239		RS1/8S332J
	R6101		RS1/8S470J
	Other Resistors		RS1/10S□□□J
OTHERS			
	BN6201	2P TERMINAL WITH PAL	AKA1017
	CN6201		KP200IA14L
		AM RF TUNING BLOCK	AXX1041
	X6203	(7.200MHZ)	ASS1042
	X6201	(456KHZ)	ASS1066
	X6202	(450KHZ)	ATF1027
MECHANISM BOARD ASSY			
SWITCHES AND RELAYS			
	S610		DSG1016
OTHERS			
	CN610	MT CONNECTOR 4P	173979-4

5. ADJUSTMENTS

5.1 TUNER SECTION

■ FM Tuner Section

- Set the mode selector to FM BAND.
- Connect the wiring as shown in Fig. 1-1.

Step No.	Adjustment Title	FM SG (1kHz, ± 75 kHz dev.)		Reception Frequency Display	Adjustment Location	Specifications
		Frequency (MHz)	Level (dB μ V)			
1	Center Adjustment	98 Non modulation	80 or more	—	L6207	Adjust so that the DC voltage between IC6201-Pin 4 and Pin 28 (or $\oplus$ leads of C6224 and C6261) becomes $0V \pm 50mV$.
2	Front End Sensitivity Adjustment	98	Low input (0 to 30)	98MHz	L6102 T6101	Adjust so that the DC voltage between the IC6201-Pin 12 and GND (or $\oplus$ leads of C6238 and GND) becomes at maximum level.
3	Stereo Distortion	98	80	98MHz	T6101	Minimize the distortion with 1/8 rotation of the core.
4	TUNED IND. Lighting Level	98	15 ± 2	98MHz	VR6201	Adjust so that the indicator of TUNED IND. starts to light up.

Notes:

- Before adjusting, make sure there is no gap between L6101 and L6102. If there is a gap between them, bring them into contact with each other first, and then make adjustments.
- Make indicator adjustments in order of AM $\rightarrow$ FM.

■ AM Tuner Section

- Set the mode selector to AM BAND.
- Connect the wiring as shown in Fig. 1-1.

Step No.	Adjustment Title	AM SG (400Hz, 30% Mod.)		Reception Frequency Display	Adjustment Location	Specifications
		Frequency (kHz)	Level (dB μ V/m)			
1	TUNED IND. Lighting Level	999*1	47 (± 2 dB)	999kHz*1	VR6202	Adjust so that the indicator of TUNED IND. starts to light up.

*1: For the area using 10 kHz step, frequencies should be 1000 kHz.




Fig. 1-1 AM and FM Adjustment Wiring Diagram

FM/AM TUNER MODULE (AXQ3213 and AXQ1012)






Fig. 1-2 Adjustment Points

5.2 CASSETTE DECK SECTION

- Adjustment points and test points are shown in Fig. 2-2 and Fig. 2-4.

■ When adjusting the Head azimuth, remove the azimuth cover (L) and (R) before adjustment.

1. Open the cassette doors (L) and (R).
2. Insert your fingers into the cassette doors, grasp both ends of the azimuth cover with your fingers, and push it a little to the front. When the azimuth cover is pushed too much at this time, the cassette doors possibly may not close.
3. Confirm that the azimuth covers (L) and (R) have been moved a little to the front, close the cassette doors (L) and (R), and remove the azimuth covers.



■ Mechanical Adjustment

- Set the TAPE function.
- Test tape: STD-301 (3kHz, 30min).

1. Tape Speed Adjustment

No.	Mode	Test Tape	Adjusting Points	Measurement Points	Adjustment Procedure	Remarks
1	Deck I PLAY	STD-301 (Playback: 3kHz)	AF Assy VR4501	TAPE TEST POINT (Rch) (AF Assy)	Press the PLAY SW and adjust so that the reading becomes $3000\text{Hz} \pm 20\text{Hz}$. Confirm that wow & flutter level is below 0.2% (in the reverse direction, confirm that the reading is within $3000\text{Hz} \pm 60\text{Hz}$).	

Electrical Adjustment

Check the following before starting.

1. Confirm that the tape speed adjustment has been completed.
2. Clean the heads and demagnetize them using a head eraser.
3. Set the measurement level to $0 \text{ dBV} = 1 \text{ Vrms}$.
4. Use the specified tape for adjustment. Use the labeled (A) side of the test tape.

STD-331E: For playback adjustment

STD-631 or STD-632: Normal blank tape

5. Provide yourself with the following measuring devices:

- AC millivoltmeter
- Low-frequency oscillator
- Attenuator
- Oscilloscope

6. Adjust both right and left channels unless otherwise specified.

7. Turn the DOLBY NR switch off unless otherwise specified.

8. Warm up the unit for several minutes before adjustment. In particular, be sure to warm up the unit in the REC/PLAY mode for 3 to 5 minutes before starting recording/playback frequency characteristics adjustment.

9. Always follow the indicated adjustment order.
Otherwise, a complete adjustment may not be achieved.

Playback Adjustment (Decks I and II)

1. Head Azimuth Adjustment
2. Playback Level Adjustment

Recording Adjustment (Deck II)

1. Bias Oscillation Frequency Adjustment
2. Recording Bias Adjustment
3. Recording Level Adjustment.
4. ALC Operation Check

**As the reference recording level is 250nwb/m for STD-331E, the recording level will be higher by 4 dB for STD-331B (160nwb/m). When adjusting, pay careful attention to the type of tape used.*

Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.

"DOLBY" and the double-D symbol  are trademarks of Dolby Laboratories Licensing Corporation.




Fig. 2-1 STD-331E Test Tape





Fig. 2-2 Head Azimuth Adjustment

PLAY BACK



RECORDING




Fig. 2-3 Frequency Characteristics

● Playback Adjustment

1. Head Azimuth Adjustment

- This unit is equipped with auto tape selector.
- Do not switch between forward and reverse operation with the screwdriver inserted.

Step	Tape Selector (AUTO)	Mode	Input Signal/ Test Tape	Adjusting Points		Measurement Points	Adjustment Value	Remarks
1	NORMAL	PLAY	STD-331E test tape (Playback: 10kHz, -20dB)	Deck I	Head azimuth adjustment screw (Fig. 2-2)	TAPE TEST POINT (L, Rch) (AF Assy)	Max. playback signal level	After adjustment, apply lock paint to the head azimuth adjustment screw.
				Deck II				

2. Playback Level Adjustment

- Since this adjustment determines playback Dolby NR level, perform it carefully.

Step	Tape Selector (AUTO)	Mode	Input Signal/ Test Tape	Adjusting Points		Measurement Points	Adjustment Value	Remarks
1	NORMAL	PLAY	STD-331E test tape (Playback: 315Hz, 0dB)	Deck I	VR4101 (Lch) VR4102 (Rch)	TAPE TEST POINT (L, Rch) (AF Assy)	-4.2 dBV	
				Deck II	VR4201 (Lch) VR4202 (Rch)			

● Recording Adjustment

1. Bias Oscillation Frequency Adjustment

Step	Tape Selector (AUTO)	Mode	Input Signal / Test Tape	Adjusting Points	Measurement Points	Adjustment Value	Remarks
1	NORMAL	REC	Load the STD-631 or STD-632 test tape and set the recording mode.	Deck I Deck II	— T4351	— Between ② point in Fig. 2-4 and GND.	Oscillation frequency to be 105.0kHz ±2kHz. When the power is turned ON while the MONO button is depressed, the frequency will decrease 2-3 kHz.

2. Recording Bias Adjustment

● After the adjustment, caution should be exercised so as not to become under bias by checking the distortion rate.

Step	Tape Selector (AUTO)	Mode	Input Signal / Test Tape	Adjusting Points	Measurement Points	Adjustment Value	Remarks
1	NORMAL	REC	Input a 315Hz signal to the VIDEO/AUX IN terminal and set the input selector to VIDEO.	Deck I Deck II	— Input signal level	TAPE TEST POINT (L, Rch) (AF Assy) -25.2 dBV	
2	NORMAL	REC → PLAY	Load the STD-631 or STD-632 test tape and record / playback the 315Hz and 10kHz signals. (see the Note below)	Deck I Deck II	— VR4351 (Lch) VR4352 (Rch)	TAPE TEST POINT (L, Rch) (AF Assy) Repeat adjustment until playback level of the 10kHz signal is within 0±0.5dB from that of the 315Hz signal.	

Note: Set the 10 kHz input signal level to the same value as the 315 Hz input signal level of step 1.

3. Recording Level Adjustment

Step	Tape Selector (AUTO)	Mode	Input Signal / Test Tape	Adjusting Points	Measurement Points	Adjustment Value	Remarks
1	NORMAL	REC	Input a 315Hz signal to the VIDEO/AUX IN terminal and set the input selector to VIDEO.	Deck I Deck II	Input signal level	TAPE TEST POINT (L, Rch) (AF Assy) -8.2 dBV	
2	NORMAL	REC → PLAY	STD-631 or STD-632 test tape and record / playback the 315Hz signal.	Deck I Deck II	— VR4301 (Lch) VR4302 (Rch)	TAPE TEST POINT (L, Rch) (AF Assy) Repeat recording, playback and adjustment until playback level of the 315Hz signal becomes -8.2dBV.	

4. ALC Operation Check

Step	Tape Selector (AUTO)	Mode	Input Signal / Test Tape	Adjusting Points	Measurement Points	Adjustment Value	Remarks
1				Input signal level		-8.2 dBV	
2	NORMAL	REC / PAUSE	Input a 315Hz signal to the VIDEO/AUX IN terminal and set the input selector to VIDEO.	Set to a level +10dB above the input level at step 1.	TAPE TEST POINT (L, Rch) (AF Assy) -3.2±2.5dBV		




Fig. 2-4 Adjusting Points and Measurement Points

5.3 CD SECTION

■ Adjustment Methods

If a disc player is adjusted incorrectly or inadequately, it may malfunction or not work at all even though there is nothing at all wrong with the pickup or the circuitry. Adjust correctly following the adjustment procedure.

● Adjustment Items/Verification Items and Order

If the specified values cannot be obtained or no adjustment is possible by performing the verifications or adjustments described in steps 1—4, the pickup block may be defective.

Step	Item	Test Point	Adjustment Location
1	Focus offset verification	CN8201, Pin6 (FE)	None
2	Tracking error balance verification	CN8201, Pin2 (TE)	None
3	Pickup radial/ tangential direction tilt adjustment	CN8201, Pin1 (RF)	Radial tilt adjustment screw, Tangential tilt adjustment screw
4	RF level verification	CN8201, Pin1 (RF)	None
5	Focus servo loop gain adjustment	CN8201, Pin5 (FI) CN8201, Pin6 (FE)	VR8152 (FOCUS)
6	Tracking servo loop gain adjustment	CN8201, Pin3 (TI) CN8201, Pin2 (TE)	VR8151 (TRACKING)

Abbreviation Table

FE : Focus Error
TE : Tracking Error
FI : Focus In
TI : Tracking In

● Measuring Instruments and Tools

1. Dual trace oscilloscope (10 : 1 probe)
2. Low-frequency oscillator
3. Test disc (VEDS - 7)
4. Low pass filter (39kΩ + 0.001μF)
5. Resistor (100kΩ)
6. 8 cm disc (With at least about 20 minutes of recording)
7. Ball point hexagon wrench (5GK1002)
8. Standard tools

● Test Point and Adjustment Variable Resistor Positions




Fig. 3-1 Adjustment Location

● Notes

1. Use a 10 : 1 probe for the oscilloscope.
2. All the knob positions (settings) for the oscilloscope in the adjustment procedures are for when a 10 : 1 probe is used.
3. GND of the oscilloscope connect to CN8201, pin4 (VC). If GND is shorted to the ground of the product, the product should be damaged.

● Test Mode

These models have a test mode so that the adjustment and checks required for service can be carried out easily. When these models are in test mode, the keys on the front panel work differently from normal. Adjustments and checks can be carried out by operating these keys with the correct procedure. For these models, all adjustments are carried out in test mode.

[Setting these models to test mode]

How to set this model into test mode.

1. When the Power switch to activated, set the FUNCTION button to CD stop mode.
2. Short-circuit between both CD TEST points. (See Fig. 3-1)

When the test mode is set correctly, the display is different from what it usually is when the power is turned on. If the display is still the same as usual, test mode has not been set correctly, so repeat Steps 1—2.

[Release from test mode]

Here is the procedure for releasing the test mode:

1. Press the STOP key and stop all operations.
2. Turn off the power switch on the front panel.

[Operations of the keys in test mode]


Code	Key Name	Function in Test Mode	Explanation
□□	DOLBY NR ON/OFF	Focus servo close	The laser diode is lit up and the focus actuator is lifted up, then lowered slowly and the focus servo is closed at the point where the objective lens is focused on the disc. With the player in this state, if you lightly rotate the stopped disc by hand, you can hear the sound the focus servo. If you can hear this sound, the focus servo is operating correctly. If you press this key with no disc mounted, the laser diode lights up, the focus actuator is pulled up, then the actuator is lowered and raised three times and returned to its original position.
◁▷	START	Spindle servo ON	Starts the spindle motor in the clockwise direction and when the disc rotation reaches the prescribed speed (about 500rpm at the inner periphery), sets the spindle servo in a closed loop. Be careful. Pressing this key when there is no disc mounted makes the spindle motor run at the maximum speed. If the focus servo does not go correctly into a closed loop or the laser light shines on the mirror section at the outermost periphery of the disc, the same symptom is occurred.
		Tracking servo close/open	Pressing this key when the focus servo and spindle servo are operating correctly in closed loops puts the tracking servo into a closed loop, displays the track number being played back and the elapsed time on the front panel, and outputs the playback signal. If the elapsed time is not displayed or not counted correctly or the audio is not played back correctly, it may be that the laser is shining on the section with no sound recorded at the outer edge of the disc, that something is out of adjustment, or that there is some other problem. This key is a toggle key and open/close the tracking servo alternately. This key has no effect if no disc is mounted.

Code	Key Name	Function in Test Mode	Explanation
-  	FAST REVERSE/ TRACK SEARCH	Carriage reverse (inwards)	Moves the pickup position toward the inner diameter of the disc. When this key is pressed with the tracking servo in a closed loop, the tracking servo automatically goes into an open loop. Since the motor does not automatically stop at the mechanical end point in test mode, be careful with this operation.
+  	FAST FORWARD/ TRACK SEARCH	Carriage forward (outwards)	Moves the pickup position toward the outer diameter of the disc. When this key is pressed with the tracking servo in a closed loop, the tracking servo automatically goes into an open loop. Since the motor does not automatically stop at the mechanical end point in test mode, be careful with this operation.
	STOP	Stop	Initializes and the disc rotation stops. The pickup and disc remain where they are when this key is pressed.
	OPEN/CLOSE	Disc tray open/close	Open /close the disc tray. This key is a toggle key and open /close tray alternately. Pressing this key when the disc is turning stops the disc, then opens the tray. This key operation does not affect the position of the pickup.

[How to playback a disc in test mode]

In test mode, since the servos operate independently, playing back a disc requires that you operate the keys in the correct order to close the servos.

Here is the key operation sequence for playing back a disc in test mode.




Wait at least 2—3 seconds between each of these operations.

1. Focus Offset Verification

● Objective	Verify the DC offset for the focus error amp.		
● Symptom when out of adjustment	The model does not focus in and the RF signal is dirty.		
● Measurement Instrument Connections	Connect the oscilloscope to CN8201, Pin6 (FE) and GND is to CN8201, Pin4 (VC). [Settings] 5mV/division 10ms/division DC mode	● Player State ● Adjustment Location ● Disc	Test mode, stopped (just the Power switch on) None None needed
[Procedure] Verify the DC voltage at CN8201, Pin6 (FE) is $0 \pm 50\text{mV}$.			

Note: If the specified values cannot be obtained or no adjustment is possible by performing the verifications or adjustments described in adjustment items 1–4, the pickup block may be defective.

2. Tracking Error Balance Verification

● Objective	To verify that there is no variation in the sensitivity of the tracking photo diode.		
● Symptom when out of adjustment	Play does not start or track search is impossible.		
● Measurement Instrument Connections	Connect the oscilloscope to CN8201, Pin2 (TE) and GND is to CN8201, Pin4 (VC). This connection may be via a low pass filter. [Settings] 50mV/division 5ms/division DC mode	● Player State ● Adjustment Location ● Disc	Test mode, focus and spindle servos closed and tracking servo open. None YEDS-7
[Procedure] 1. Move the pickup to midway across the disc (R=35mm) with the FORWARD/TRACK SEARCH + ▷▷ ▷▷ key or REVERSE ◁◁◁◁ - key. 2. Press the DOLBY NR ■■ key, then the START ◁ ▷ key in that order to close the focus servo then the spindle servo. 3. Line up the bright line (ground) at the center of the oscilloscope screen and put the oscilloscope into DC mode. 4. Supposing that the positive amplitude of the tracking error signal at CN8201, pin2 (TE) is (A) and the negative amplitude is (B), the following expression is satisfied.			
When $A \geq B$, $\frac{A-B}{C} \times \frac{1}{2} \leq 0.1$ When $A < B$, $\frac{B-A}{C} \times \frac{1}{2} \leq 0.1$			

3. Pickup Radial/Tangential Tilt Adjustment

● Objective	To adjust the angle of the pickup relative to the disc so that the laser beams are shone straight down into the disc for the best read out of the RF signals.		
● Symptom when out of adjustment	Sound broken; some discs can be played but not others.		
● Measurement Instrument Connections	Connect the oscilloscope to CN8201, Pin1 (RF) and GND is to CN8201, Pin4 (VC). [Settings] 20mV/division 200ns/division AC mode	● Player State ● Adjustment Location ● Disc	Test mode, play Pickup radial tilt adjustment screw and tangential tilt adjustment screw 8 cm disc [However, those with approx. 20 min of audio signal (music).]

[Procedure]

1. Press the FORWARD/TRACK SEARCH + ▷▷ ▷▷ key or REVERSE ◁◁◁◁ - key to move the pickup to the external circumference of the disc.
Press the DOLBY NR □□ key, the START ◁ ▷ key twice in that order to close the respective servos and put the player into play mode.
2. First, adjust the radial tilt adjustment screw with the hexagon wrench (GGK1002) so that the eye pattern (the diamond shape at the center of the RF signal) can be seen the most clearly.
3. Next, adjust the tangential tilt adjustment screw with the hexagon wrench (GGK1002) so that the eye pattern (the diamond shape at the center of the RF signal) can be seen the most clearly (Fig. 3-3).
※ The ball-point type hexagonal wrench is used because the disc will get in the way if a normal hexagonal wrench is used.
4. Adjust the radial tilt adjustment screw and the tangential tilt adjustment screw again so that the eye pattern can be seen the most clearly. As necessary, adjust the two screws alternately so that the eye pattern can be seen the most clearly.
5. When the adjustment is completed, lock the radial and tangential adjustment screw.

Note: Radial and tangential mean the directions relative to the disc shown in Fig. 3-2.





Fig. 3-2






Fig. 3-3 Eye Pattern

4. RF Level Verification

● Objective	To verify the playback RF signal amplitude.		
● Symptom when out of adjustment	No play or no search		
● Measurement Instrument Connections	Connect the oscilloscope to CN8201, Pin1 (RF) and GND is to CN8201, Pin4 (VC). [Settings] 50mV/division 10ms/division AC mode	● Player State ● Adjustment Location ● Disc	Test mode, play None YEDS-7
[Procedure] 1. Move the pickup to midway across the disc (R=35mm) with the FORWARD/TRACK SEARCH + ▷▷ ▷▷ key or REVERSE ◁◁◁◁ - key, then press the DOLBY NR ■■ key, the START ◁ ▷ key twice in that order to close the respective servos and put the player into play mode. 2. Verify the RF signal amplitude is $1.2V_p - p \pm 0.2V$.			

5. Focus Servo Loop Gain Adjustment

● Objective	To optimize the focus servo loop gain.		
● Symptom when out of adjustment	Playback does not start or focus actuator noisy.		
● Measurement Instrument Connections	See Fig. 3-4. [Settings] CH1 20mV/division X-Y mode CH2 5mV/division	● Player State ● Adjustment Location ● Disc	Test mode, play VR8152 (FOCUS) YEDS-7

[Procedure]

1. Set the AF generator output to 1.2kHz and 1Vp-p.
2. Press the FORWARD/TRACK SEARCH + ▷▷ ▷▷ key or REVERSE ◁◁◁◁ - key to move the pickup to halfway across the disc (R=35mm), then press the DOLBY NR □□ key, the START ◁ ▷ key twice in that order to close the corresponding servos and put the player into play mode.
3. Adjust VR8152 (FOCUS) so that the Lissajous waveform is symmetrical about the X axis and the Y axis.





Fig. 3-4

Focus Gain Adjustment



Higher gain



Optimum gain



Lower gain

6. Tracking Servo Loop Gain Adjustment

● Objective	To optimize the tracking servo loop gain.		
● Symptom when out of adjustment	Playback does not start, during searches the actuator is noisy, or tracks are skipped.		
● Measurement Instrument Connections	See Fig. 3-5. [Settings] CH1 50mV/division X-Y mode CH2 20mV/division	● Player State ● Adjustment Location ● Disc	Test mode, play VR8151 (TRACKING) YEDS-7

[Procedure]

1. Set the AF generator output to 1.2kHz and 2Vp-p.
2. Press the FORWARD/TRACK SEARCH + ▷▷▷ key or REVERSE ◁◁◁ - key to move the pickup to halfway across the disc (R=35mm), then press the DOLBY NR □□ key, the START ◁▷ key twice in that order to close the corresponding servos and put the player into play mode.
3. Adjust VR8151 (TRACKING) so that the Lissajous waveform is symmetrical about the X axis and the Y axis.






Fig. 3-5

Tracking Gain Adjustment



Higher gain



Optimum gain




Lower gain

6. IC INFORMATION

- The information shown in the list is basic information and may not correspond exactly to that shown in the schematic diagrams.

■ PDG148B (IC1901 : DISPLAY ASSY)

- Display Control Micro-computer
- Pin Assignment (Top view)



● Pin Function


No.	Pin Name	I/O	Description	ACT
1	OPEN	I	Tray open acknowledge	L
2	REMOTE	I	Remote control signal input	
3	CLAMP	I	CD clump acknowledge	L
4	$\overline{\text{LD ON}}$	O	Laser diode light up	L
5	CD RESET	O	Decoder (2508) reset	L
6	P. ON	O	System power	H
7	CD XLT	O	Latch after decoder transfer	
8	CD CLK	O	Decoder clock	
9	SQSO	I	Disc time information	H
10	CD DATA	O	Decoder data	
11	S. CLK	O	PLL, PM0006, 4094 clock	

No.	Pin Name	I/O	Description	ACT
12	PLL CE	O	PLL Enable/Request	
13	S. DATA	O	PLL, PM0006, 4094 data	
14	0006CE	O	0006 Enable/Request	
15	EXCE	O	BU4094 Enable/Request	
16	SOL1	O	Deck mechanism I solenoid control	H
17	SOL2	O	Deck mechanism II solenoid control	H
18	MOTOR	O	MOTOR ON/OFF	L
19	KI1	I	Key return input I	H
20	KI2	I	Key return input II	H
21	KI3	I	Key return input III	H
22	STEREO/TUNE	I	0 2.5 5.0 STEREO/TUNE TUNE	
23	60	I	Detection signal input for spectrum analyzer	
24	400	I		
25	2.4K	I		
26	15K	I		
27	PROTECTION	I	Power IC protection circuit. Standby at 1.0V. Indication during protection operation.	H
28	PULSE1	I	Deck mechanism I operation acknowledge	H
29	PULSE2	I	Deck mechanism II operation acknowledge	H
30	RESET	I	Reset input	
31	EXTL	I	Connected to oscillator (8MHz)	
32	XTL	I		
33	VSS	—	Connected to GND	
34	CD	O	Function LED	L
35	REC	O		


TDA7265 (IC1201: AF ASSY)

● 25W + 25W Stereo Amplifier with Mute & ST-BY

● Pin Assignment (Top view)



● Block Diagram



No.	Pin Name	I/O	Description	ACT
36	TAPE	O	Function LED	L
37	AUX	O		
38	TX	O		
39	◁	O		
40	▷	O		
41 56	S16 S1	O	FL segment output / Key scan output	
57 70	G14 G1	O	FL grid output	
71	VFDP	-	Connected to -30V	
72	VDD	-	Connected to +5V	
73		-	Connected to +5V	
74	FCOK	I	Decoder monitor H: FOCUS OK	H
75	INSD	I	Pickup home position acknowledge	L
76	SENSE	I	Decoder monitor	
77	CD XLT ON/OFF	O	XTAL ON/OFF	L/H
78	AC50/60	I	AC Clock (reading power supply frequency)	
79	GFS	I	Decoder monitor Rotation speed frame check	H: OK
80	SCOR	I	Decoder monitor Q data interrupt signal	H

BU4094BCF (IC1981: AF ASSY)
● Expander I
● Pin Function

No.	Pin Name	I/O	Description	ACT
1	ST	I	STROB	
2	DT	I	DATA	
3	CK	I	CLOCK	
4	PB/REC	O	Dolby IC (CXA1101P) Switching PB/REC H: PB L: REC	
5	ON/OFF	O	Dolby IC (CXA1101P) □□ ON/OFF H: OFF L: ON	
6	PB 1/2	O	Switching playback I / II H: I, L: II	
7	REC MUTE	O	REC mute	H
8	VSS	—	GND	
9	Qs			
10	Q's			
11	BIAS CONT	O	Bias ON/OFF	H
12	BEAT CUT	O	Beat cut ON/OFF	H
13	S. MUTE	O	System mute	L
14		O	Not used	
15	OE			
16	VDD	—	+5V power supply	

BU4094BCF (IC1982: AF ASSY)
● Expander II
● Pin Function

No.	Pin Name	I/O	Description	ACT																				
1	ST	I	STROB																					
2	DT	I	DATA																					
3	CK	I	CLOCK																					
4	A	O	Switching function <table><tr><td></td><td>A</td><td>B</td><td>INH</td></tr><tr><td>TX</td><td>L</td><td>L</td><td>L</td></tr><tr><td>TAPE</td><td>L</td><td>H</td><td>L/(H)</td></tr><tr><td>CD</td><td>H</td><td>L</td><td>L</td></tr><tr><td>AUX</td><td>H</td><td>H</td><td>L</td></tr></table>		A	B	INH	TX	L	L	L	TAPE	L	H	L/(H)	CD	H	L	L	AUX	H	H	L	
	A	B		INH																				
TX	L	L		L																				
TAPE	L	H		L/(H)																				
CD	H	L		L																				
AUX	H	H	L																					
5	B	O																						
6	INH	O	Function Tape: INH H																					
7	L IN	O	Tray load in	H																				
8	VSS	—	GND																					
9	Qs																							
10	Q's																							
11	DOWN	O	Volume UP/DOWN <table><tr><td></td><td>No. 11</td><td>No. 12</td></tr><tr><td>UP</td><td>H</td><td>L</td></tr><tr><td>DOWN</td><td>L</td><td>H</td></tr><tr><td>STOP</td><td>L</td><td>L</td></tr></table>		No. 11	No. 12	UP	H	L	DOWN	L	H	STOP	L	L									
	No. 11	No. 12																						
UP	H	L																						
DOWN	L	H																						
STOP	L	L																						
12	UP	O																						
13	MONO	O	TX Execution MONO	H																				
14	LOUT	O	Tray load out	H																				
15	OE																							
16	VDD	—	+5V power supply																					

AAV7012 (V1901: DISPLAY ASSY)

-
- Figure 1 is a schematic diagram of a radio receiver's frequency scale and tuning circuit. The top part shows a frequency scale from 146 to 106 MHz, with various tuning controls and indicators. The bottom part shows a detailed view of the tuning circuit components, including a variable capacitor and a coil, with labels for various points and components.
- The frequency scale is marked with the following values: 146, 136, 96, 86, 76, 66, 56, 46, 36, 26, 16. The scale is divided into sections by vertical dashed lines. The top section is labeled "AUTO OFF", "PGM", "RPT", and "SFC". The middle section is labeled "TUNED", "STEREO", and "MONO". The bottom section is labeled "A.T.U.N.", "MHz", and "kHz".
- The tuning circuit components are labeled with various letters and numbers. The variable capacitor is labeled with "a", "b", "c", "d", "e", "f", "g", "h", "i", "j", "k", "l", "m", "n", "o", "p", "q", "r", "s", "t", "u", "v", "w", "x", "y", "z". The coil is labeled with "1", "2", "3", "4", "5", "6", "7", "8", "9", "10", "11", "12", "13", "14", "15", "16".
- The diagram also shows various other components and labels, including "136", "106-126", "16 146", "136", "106-126", "16 146", "136", "106-126", "16 146".

[illegible]

Pin No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
Assignment	F1	F1	NL	G14	G13	G12	G11	G10	G1	NL	NL	NL	NL	NL	NL	NL	NL	NL	NL	NL	NL	NL
Pin No.	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44
Assignment	G4	G3	G2	G1	G10	S11	S12	S13	S14	S8	S7	S6	S5	S4	S3	S2	S1	S15	S16	NL	F2	F2

Pin: F2: Pinament G1~G14:Grind S1~S16:Anode NL:No Lead NP:No Pin

8. FOR MEXK/EA, MEXK/EB AND SD TYPES

NOTES :

- Parts marked by "NSP" are generally unavailable because they are not in our Master Spare Parts List.
- The Δ mark found on some component parts indicates the importance of the safety factor of the part. Therefore, when replacing, be sure to use parts of identical designation.
- Parts marked by "●" are not always kept in stock. Their delivery time may be longer than usual or they may be unavailable.
- When ordering resistors, first convert resistance values into code form as shown in the following examples.

Ex. 1 When there are 2 effective digits (any digit apart from 0), such as 560 ohm and 47k ohm (tolerance is shown by J = 5%, and K = 10%).
 $560\Omega \rightarrow 56 \times 10^1 \rightarrow 561$ $RD1/8PM[5][6][1]J$
 $47K\Omega \rightarrow 47 \times 10^3 \rightarrow 473$ $RD1/4PS[4][7][3]J$
 $0.5\Omega \rightarrow 0R5$ $RN2H[0][R][5]K$
 $1\Omega \rightarrow 010$ $RS1P[0][1][0]K$
Ex. 2 When there are 3 effective digits (such as in high precision metal film resistors).
 $5.62K\Omega \rightarrow 562 \times 10^1 \rightarrow 5621$ $RM1/4PC[5][6][2][1]F$

MEXK/EA, MEXK/EB, SD types and NBXK type have the same construction except for the following :

Mark	Symbol & Description	Part No.				Remarks
		NBXK type	MEXK/EA type	MEXK/EB type	SD type	
NSP	COMPLETE assy AF assy DISPL.AV assy PRIMARY assy HEADPHONE assy	AWK7113 AWZ7501 AWZ7504 AWZ7509 AWZ7514	AWK7113 AWZ7501 AWZ7504 AWZ7509 AWZ7514	AWK7113 AWZ7501 AWZ7504 AWZ7509 AWZ7514	AWK7116 AWZ7503 AWZ7506 AWZ7512 AWZ7516	
NSP	FM/AM TUNER MODULE	AXQ3213	AXQ3213	AXQ3213	AXQ1012	
Δ	Voltage selector	Not used	Not used	Not used	AKX-507	*1
Δ	Power transformer (AC220-230V)	ATS7054	ATS7054	ATS7054	Not used	
Δ	Power transformer (AC110-115V/120-127V/220-230V/240V)	Not used	Not used	Not used	ATS7056	
Δ	AC power cord	ADG1148	ADG1138	ADG1138	PDG1013	
Δ	Fuse (T5A)	AEX1046	Not used	Not used	AEX1051	*1
Δ	Fuse (T500mA, FU2)	Not used	Not used	Not used		
NSP	From panel	AZN7207	AZN7207	AZN7207	AZN7203	
	Cassette door L	AZN7208	AZN7208	AZN7208	AZN7204	
	Cassette door R	AZN7209	AZN7209	AZN7209	AZN7205	
	Mic knob	Not used	Not used	Not used	AAB7052	*1
	Chassis	ANA7020	ANA7020	ANA7020	ANA7017	
	Bracket	AZN7210	AZN7210	AZN7210	AZN7206	
	Rear panel	ANC7215	ANC7216	ANC7213	ANC7213	
	Eject spring L	ABH7028	ABH7028	ABH7028	RBH1411	
	Eject spring R	ABH7029	ABH7029	ABH7029	RBH1412	
	Door spring L	ABH7060	ABH7060	ABH7060	ABH7058	
	Door spring R	ABH7061	ABH7061	ABH7061	ABH7059	
	Connector assy (SP)	ADX7045	ADX7045	ADX7045	RSP1582	

Note *1: Refer to "2. EXPLODED VIEWS, PACKING AND PARTS LIST".

Mark	Symbol & Description	Part No.				Remarks
		NBXK type	MEXK/EA type	MEXK/EB type	SD type	
NSP	Power pack holder	ANG7025	ANG7025	ANG7025	ANG7020	
NSP	Heat sink	ANH7015	ANH7015	ANH7015	ANH7014	
NSP	FM antenna	ADH1019	ADH1019	ADH1019	ADH1016	
NSP	Battery (R03, AAA)	PEM1004	PEM1004	PEM1004	VEA-009	
NSP	Packing case	AHD7135	AHD7182	AHD7182	AHD7126	
NSP	Front pad	AHA7054	AHA7054	AHA7054	AHA7052	
NSP	Rear pad	AHA7055	AHA7055	AHA7055	AHA7053	
NSP	Packing sheet	AHG7001	AHG7001	AHG7001	AHG7003	
NSP	Spacer	AHB7006	Not used	Not used	Not used	
NSP	Caution label (G)	VRW-329	VRW-329	VRW-329	Not used	
NSP	Caution label (F)	ARW1046	ARW1046	ARW1046	Not used	
NSP	Caution label	ARW1050	ARW1047	ARW1047	Not used	
NSP	Operating instructions (English)	ARB7033	Not used	ARB7033	Not used	
NSP	Operating instructions (French/Swedish/Spanish/Portuguese)	Not used	Not used	ARC7057	Not used	
NSP	Operating instructions (German/Italian)	Not used	ARC7053	Not used	Not used	
NSP	Operating instructions (French/Dutch)	Not used	ARC7054	Not used	Not used	
NSP	Operating instructions (English/Spanish/Chinese)	Not used	Not used	Not used	ARE7034	
NSP	Quick set up guide (English)	ARB7039	Not used	Not used	Not used	

AF Assy

AWZ7503 and AWZ7501 have the same construction except for the following :

Mark	Symbol & Description	Part No.		Remarks
		AWZ7501	AWZ7503	
C1984, C2507	Not used	Not used	CKSQYB102X50	*2
	CKCYB103X50	Not used	CKSQYB103X50	
	C2202	Not used	CEAS100M50	*2
	C2213, C2214	CEAS221M10	CEAS221M16	
R1996	Not used	Not used	RS1/1052221	*2
	R2000	Not used	RS1/6PM2221	*2
	R2213	Not used	RS1/1051022	*2
	R2218	RS1/1051022	Not used	
R9019	Not used	Not used	RS1/1050001	*2

Note *2: Refer to "SCH-3 to SCH-5".

PRIMARY Assy

AWZ7512 and AWZ7509 have the same construction except for the following :

Mark	Symbol & Description	Part No.		Remarks
		AWZ7509	AWZ7512	
	H1103, H1104 Fuse holder	Not used	VKR1001	

DISPLAY Assy

AWZ7506 and AWZ7504 have the same construction except for the following :

Mark	Symbol & Description	Part No.		Remarks
		AWZ7504	AWZ7506	
	D9001	1SS254	Not used	
	D9008, D9012	Not used	1SS254	*3
	C2501, C2508	Not used	CKSQYB473K50	*3
	C2502	Not used	CEAS010M50	*3
	C2503	Not used	CEAS100M50	*3
	C2504	Not used	CKSQYB821K50	*3
	VR2501 (10k-B)	Not used	ACS1097	*3
	R2502	Not used	RS1/10S821J	*3
	R2503	Not used	RS1/10S104J	*3
	R2504	RS1/10S103J	RS1/10S332J	
	R2506	Not used	RS1/10S152J	*3
	R2507	RS1/10S000J	RS1/10S683J	
	R2508	Not used	RS1/10S101J	*3

Note *3: Refer to "SCH-6".

HEADPHONE Assy

AWZ7516 and AWZ7514 have the same construction except for the following :

Mark	Symbol & Description	Part No.		Remarks
		AWZ7514	AWZ7516	
	L2501	Not used	LAU2R2J	*4
	L2502	LAU100J	LAU2R2J	
	C2505	Not used	CKSQYF104Z50	*4
	CN2501	Not used	AKN1028	*4

Note *4: Refer to "SCH-5".


FM/AM TUNER MODULE

AXQ1012 and AXQ3213 have the same construction except for the following :

Mark	Symbol & Description	Part No.		Remarks
		AXQ3213	AXQ1012	
	C6202 (1μF/16V)	Not used	ACG1051	*5
	C6230	CKSQYB273K50	CKSQYB333K50	
	C6232	CKSYB273K50	CKSYB333K50	
	C6251	CKSYB822K50	CKSYB472K50	
	C6252	CKSQYB822K50	CKSQYB472K50	
	C6268	Not used	CCSQCH101J50	*5
	C6269	CCSQCH101J50	Not used	
	C6270 (1μF/16V)	ACG1051	Not used	
	R6288	RS1/10S000J	RS1/10S471J	
	BN6201 Terminal 2P with PAL	AKA1017	Not used	
	BN6201 Terminal 4P	Not used	AKA1016	*5

Note *5: Refer to "SCH-2".

9. PANEL FACILITIES



- ① CD Disc tray
- ② AUTO button
- ③ Remote sensor
- ④ POWER STANDBY/ON switch and STANDBY indicator

This is the switch for electric power.

ON: When set to the ON position, power is supplied and the unit becomes operational.


STANDBY: When set to the STANDBY position, the main power flow is cut and the unit is no longer fully operational. A minute flow of power feeds the unit to maintain operation readiness. (The STANDBY indicator lights.)

- ⑤ TIMER REC/WAKE-UP button
- ⑥ CLOCK/CLOCK ADJ button

- ⑦ Headphones jack

- ⑧ SFC button

Each time this button is pressed, the mode changes in the following sequence:



NOTE:


If KARAOKE is selected, the vocal part in songs is muted and only the instrumental accompaniment (backing) is played.

- ⑨ TAPE I cassette door
- ⑩ TAPE I eject button (▲)
- ⑪ CD OPEN/CLOSE button (▲)
- ⑫ MEMORY button
- ⑬ FREQ/STATION button
- ⑭ VOLUME control
- ⑮ MONO button
- ⑯ P.BASS (DEMO) button
- ⑰ Rec standby button and indicator (●)
- ⑱ Dolby* NR ON/OFF button
- ⑲ ST.WIDE button
- ⑳ TAPE II cassette door
- ㉑ TAPE II eject button (▲)
- ㉒ Function buttons (Refer to p. 65)

*

- Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.
- "DOLBY" and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

Function button section



- ① ◀, ▶ buttons
- ② TAPE (I/II) function button and indicator
- ③ VIDEO function button and indicator
- ④ STOP button (■)
- ⑤ START button (▶)
- ⑥ Tuner (FM/AM) function button and indicator
- ⑦ CD function button and indicator

• Roles of the common operation buttons (The rules of the buttons vary depending on the input functions as shown below.)

During CD input

START: Play/pause button

STOP: Stop button

▶▶: Fast forward/track search button

◀◀: Fast reverse/track search button

During cassette deck input

START: Play button/Tape transport direction

STOP: Stop button

▶▶: Fast forward button


◀◀: Rewind button

During tuner operation

▶▶: Frequency Up button


◀◀: Frequency Down button

REMOTE CONTROL UNIT



① **Function button (FUNC)**

Each time this button is pressed, the function changes in the following sequence:



② **SFC mode button**

③ **SLEEP timer button**

④ **DISPLAY button**

⑤ **REPEAT button**

⑥ **PGM button**

⑦ **Number buttons**

These buttons are used for selecting track numbers of a CD and for scanning preset stations.

⑧ **CD operation buttons**

(Track search ◀◀▶▶, Stop ■, Play/Pause ▶/II)

⑨ **TAPE I operation buttons**

(Fast ◀◀▶▶, Stop ■, Play ▶▶)

⑩ **TAPE II operation buttons**

(Fast ◀◀▶▶, Stop ■, Play ▶▶)

⑪ **STATION - (down), + (up) buttons**

Before operation, memorize broadcast stations with the STATION -, + buttons.

+ Stations change in order in the upward direction.

- Stations change in order in the downward direction.

⑫ **FM/AM band button**

⑬ **POWER button**

⑭ **VOLUME + (up), - (down) button**

Increase/decrease the sound volume of the unit.

10. SPECIFICATIONS

STEREO CD CASSETTE DECK RECEIVER

Amplifier section

Continuous Power Output (RMS) 25 W + 25 W
(1 kHz, T.H.D. 10 % 8)

Continuous Power Output (DIN) 20 W + 20 W
(1 kHz, T.H.D. 1 % 8)

- Above specifications are for when power supply is 230 V.

FM/AM Tuner section

FM tuner section

Frequency Range 87.5 MHz to 108 MHz

Antenna input 75 unbalanced

AM tuner section

Frequency Range

With 9 kHz step ... 531 kHz to 1,602 kHz

Antenna Loop antenna

CD section

Type Compact disc digital audio system

Wow and Flutter Limit of measurement
(± 0.001 % W.PEAK) or less

Cassette deck section

Systems 4 track, 2-channel stereo

Heads Recording/playback head x 1

Playback head x 1

Erasing head x 1

Motor DC servo motor x 1

Tape type ... TYPE I (Normal) tape

Miscellaneous

Power Requirements ... AC 230 V AC, 50/60 Hz (U K model)

AC 220 - 230 V AC, 50/60 Hz (European model)

Power Consumption 100 W

Dimensions 240 (W) x 270 (H) x 293 (D) mm

Weight (without package) 5.3 kg

Accessories

Operating instructions 1

Remote control unit 1

AAA/R03 dry cell batteries 2

FM T-type antenna 1

AM loop antenna 1

NOTE:

Specifications and design subject to possible modification without notice, due to improvement.